




## User Manual



# L18

Tactical Far Throw Distance Flashlight

### Features

- Pocket tactical flashlight - compact, lightweight, and portable
- Be able to deliver maximum 2,100 lumens by green LED(1,500 lumens by white LED)
- A super far-reaching throw of 1,155 meters by green LED(1,000 meters by white LED)
- Powered by a 5100mAh 21700 battery, max runtime of 94 days
- Acebeam USB rechargeable 21700 Li-ion battery can be optional
- Dual switches for easy and fast operation
- An update PMMA lens provides better light quality with a soft and balanced beam
- The aggressive strike bezel is used to break windows or defend in an emergency situation
- Highly efficient constant current circuit design (Non-PWM)
- The power indicator indicates the remaining battery power
- Lockout mode prevents accidental activation
- Intelligent temperature regulation and protection adjusts output performance to prevent overheating
- Aerospace-grade aluminum body with a hard-anodized finish
- Compatible with Acebeam ARPS-R02 Remote Pressure Switch

### Specifications

Dimensions: 154mm (Length) x 52.2mm (Head Diameter) x 25.4mm (Tube Diameter)  
Weight: 147.5g w/ battery

### Accessories

1x Holster; 1x Pocket clip; 1x Lanyard; 1x Spare rubber button cap; 2x O-rings; 1x Warranty card;  
1x User manual; 1x Battery warning card

### Technical Parameter

FL1 STANDARD	Turbo	High	Mid2	Mid1	Low	Moonlight	Strobe
	1500 lumens	750 lumens	390 lumens	190 lumens	53 lumens	1 lumen	900 lumens
	1h 30min	2h 15min	5h	12h	47h	94days	3h
	1000m	697m	520m	369m	220m		
	250,000cd	121,452cd	67,600cd	34,040cd	12,100cd		
	2100 lumens	1150 lumens	600 lumens	300 lumens	80 lumens	1 lumen	1100 lumens
	1h 30min	2h 15min	5h	12h	47h	94days	3h
	1155m	821m	598m	413m	317m		
	334,000cd	168,600cd	89,600cd	42,800cd	25,200cd		

Notice: The above mentioned parameters (tested with 1x ACEBEAM 21700 5100mAh battery) are approximate and may vary from flashlights, batteries, and environments. The L18 needs to be installed 1x 21700 5100mAh high drain battery that can produce at least 10 Amps of current. The Turbo output is measured in total of runtime including output at step-down levels due to temperature regulation or protection mechanism.

### Operation Instruction

#### Tactical Tail Switch:

When the flashlight is unlocked, click the tactical tail switch for momentary on and constant activation at Turbo mode.

Please note if click the tactical tail switch at first, Any operation of side switch is useless.

#### Side Switch:

**ON/OFF:** Single click the side switch.

**Mode Selection:** When the flashlight is ON, press and hold the side switch to cycle from Low →Med1 →Med2 →High modes, loosen the switch at your selected mode, Next ON will memorize the last mode you selected.

**Turbo:** Double click the side switch to exchange between Turbo mode and memorized mode.

**Strobe:** Triple click to access Strobe mode regardless the flashlight is ON or OFF.

**Moonlight:** When the flashlight is OFF, press and hold the side switch for 0.5 second goes to Moonlight.

#### Lock

When the flashlight is OFF, press and hold the side switch for 5 seconds, the flashlight will be Locked after 3 seconds' Moonlight output. It is useless for both side switch operation and

tactical tail switch.

#### Unlock

When the flashlight is Locked , press and hold the side switch for 3 seconds, the flashlight will be Unlocked and light at Moonlight mode.

**(Remark: To unlock, the tail switch needs to be turned off firstly, the power indicator**

**can indicate the tail switch is on or off)**

Moonlight and Turbo can not be memorized.

### Power Indicator

Green light: >30%

Red light: among 30%~ 10%, low battery warning

Red flash light: below 10%

### Warning

1. By using this device, you certify you have read the included User Manual and Warning Card and release the manufacturer and retailers from all liabilities.
2. Please use in accordance with applicable laws and regulations.
3. Quality batteries with circuit protection will reduce the potential risk.
4. Do not aim this light directly at eyes or exposed skin to prevent injuries. Keep this flashlight out of the reach of children.

### Usage and Maintenance

1. Unauthorized disassembly may damage the light and void the warranty.
2. This is normal case the light will accumulate a lot of heat when used on Turbo/ Turbo- Max output levels for extended periods. When the lamp reaches a temperature of 65 °C or above, the lamp will automatically step down a few lumens to reduce the temperature. When the temperature drops below 65 °C, it will then allow the user for the reselection of the modes.
3. Lubricate the threads with professional grade lubricant regularly.
4. Please swap out the O-rings regularly to maintain the water resistance level.
5. Maintain and keep clean any contact surfaces of the flashlight with alcohol swab. This may prevent irregular flashes during use.
6. Remove batteries during storage. Keep lithium-ion batteries charges approximately every 4 months.
7. This flashlight may not be used as diving light.

### Product Warranty

1. If the customer experiences any problems with an Acebeam product within 15 days of purchase, the dealer will replace that product.
2. If an Acebeam flashlight fails during normal use within a period of five years (60 months) of purchase, the dealer will repair or replace the flashlight with the same or similar model.
3. ACEBEAM Batteries, accessories and lanterns with built-in batteries are warranted for a period of one year (12 months) from date of purchase.
4. Warranty one year (12 months) for magnetic charging products.
5. The warranty does not cover damage or failure caused by:
  - A. Rough usage or operation which does not comply with the user manual or product specifications.
  - B. Unauthorized disassembly, repair or modification. Defects or damaged caused by factors out of Acebeam's control.
  - C. Battery leakage damaged products.
6. If there are any questions about ACEBEAM products, please consider the warranty and contact Acebeam or your original Acebeam dealer for warranty return instructions.  
Email: info@acebeam.com

SHENZHEN ZENBON TECHNOLOGY CO., LTD  
+86-0755-23036551  
www.acebeam.com  
info@acebeam.com  
4/F, 3rd Building, Yijiang Industrial Park, Dalang,  
Longhua, Shenzhen 518100, Guangdong, China

Copyright © 2021 ACEBEAM. All rights reserved.  
Powered by Shenzhen Zenbon Technology Co., Ltd

